


4. Digital Loader Operation

Prior to connecting power and turning ON the servo, check the parameters [Motor parameters (P1--)] related to the motor at the digital loader. In order for the servo system to operate satisfactorily based on the information on the motor connected to the servo, accurate value must be set.

Next, monitor [Status Window (St--)] and verify that all commands and limit values are properly set.


For initial operation, verify certain degree of stability through autotuning and trial operation (jog, simulation). Autotuning can be achieved through on-line system, but it is not necessary to use this function in case stabilized control gain is acquired through off-line system.



External view of digital loader

4.1 Handling and Menu system

-  PROG Moves from main menu to sub-menu; Start editing
-  MODE Moves from main menu to main menu or from sub-menu to main menu
-  Moves between sub-menus



4.2 Changing Parameters

The parameter value can be changed in the same method.

Even though the changeable range varies according to menu, operation methods are the same.

Hence, [Motor ID (P1-01)] is presented here as a representative example.

 PROG Starts parameter editing and cancels parameter change

 ENTER Verifies changed parameter

 Increases or decreases cursor position value

 Moves cursor to left or right

